



AMAZÔNIA



AMAZÔNIA 37004630
Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41
△ 2415 gr A 55 mm Ø 410 mm
△ 5 1/5 lbs H 2 1/8" Ø 16 1/2"



AMAZÔNIA 37004635
Travessa Oval 39
Oval Platter 39
Fuente Oval 39
Plat Ovale 39
△ 1580 gr A 35 mm C 385 mm L 330 mm
△ 3 1/2 lbs H 1 3/8" L 15 1/8" W 13"



AMAZÔNIA 37004632
Prato Marcador 34
Charger Plate 34
Plato Presentación 34
Assiette de Présentation 34
△ 1111 gr A 35 mm Ø 335 mm
△ 2 4/5 lbs H 1 3/8" Ø 13 1/2"



AMAZÔNIA 37004637
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 770 gr A 25 mm Ø 280 mm
△ 1 2/5 lbs H 1" Ø 11"



AMAZÔNIA 37004642
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 595 gr A 45 mm C 220 mm L 210 mm
△ 1 1/5 lbs H 1 7/8" L 8 3/8" W 8 1/4"

AMAZÔNIA



AMAZÔNIA 37004636

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 830 gr A 45 mm C 280 mm L 270 mm CAP. 560 ml

△ 1 ½ lbs H 1 7/8" L 11" W 10 5/8" CAP. 18 9/16 oz



AMAZÔNIA 37004627

Prato Sobremesa 24

Dessert Plate 24

Plato Postre 24

Assiette Dessert 24

△ 485 gr A 25 mm C 235 mm L 230 mm

△ 1 lbs H 1" L 9 ¼" W 9"



AMAZÔNIA 37004641

Prato Pão 18

Bread & Butter Plate 18

Plato Pan 18

Assiette à Pain 18

△ 346 gr A 25 mm Ø 175 mm

△ ¾ lbs H 1" Ø 6 7/8"



AMAZÔNIA 37004640

Saladeira 26

Salad Bowl 26

Ensaladera 26

Saladier 26

△ 1000 gr A 110 mm C 260 mm L 250 mm CAP. 1520 ml

△ 2 ½ lbs H 4 ½" L 10 ¼" W 9 5/8" CAP. 51 2/5 oz



AMAZÔNIA 37005066*

Taça 35

Bowl 35

Taza 35

Bol 35

△ 1111 gr A 120 mm C 345 mm L 330 mm CAP.

3200 ml

△ 2 4/5 lbs H 4 5/8" L 13 4/7" W 13" CAP. 108 1/5 oz



AMAZÔNIA 37005067*

Taça 24

Bowl 24

Taza 24

Bol 24

△ 950 gr A 100 mm C 240 mm L 220 mm

CAP. 1300 ml

△ 2 lbs H 4" L 9 4/8" W 8 3/8" CAP. 44 oz

AMAZÔNIA



AMAZÔNIA 37005069*

Travessa 32

Tray 32

Fuente 32

Plat 32

△521 gr A 45 mm C 315 mm L 115 mm

△ 1 1/2 lbs H 1 7/8" L 12 3/8" W 4 1/2"



AMAZÔNIA 37005068*

Travessa 45

Tray 45

Fuente 45

Plat 45

△715 gr A 15 mm C 450 mm L 130 mm

△ 1 3/4 lbs H 3/8" L 17 5/8" W 5 1/8"



AMAZÔNIA 37004626

Taça 17

Bowl 17

Taza 17

Bol 17

△400 gr A 55 mm C 170 mm L 155 mm CAP. 450 ml

△ 7/8 lbs H 2 1/6" L 6 3/8" W 6 1/8" CAP. 15 3/8 oz



AMAZÔNIA 37004631

Taça 11

Bowl 11

Taza 11

Bol 11

△146 gr A 35 mm C 105 mm L 100 mm CAP. 70 ml

△ 1/2 lbs H 1 3/8" L 4 1/8" W 3 9/8" CAP. 2 3/8 oz



AMAZÔNIA 37004639

Taça 10

Bowl 10

Taza 10

Bol 10

△191 gr A 60 mm C 100 mm L 95 mm CAP. 170 ml

△ 3/7 lbs H 2 3/8" L 3 3/8" W 3 3/4" CAP. 5 3/4 oz

AMAZÔNIA



AMAZÔNIA 37004638

Caneca 400 ml

Mug 400 ml

Jarra 400 ml

Tasse 400 ml

△ 266 gr A 110 mm C 120 mm L 90 mm CAP. 400 ml

△ ½ lbs H 4 ½" L 4 ¾" W 3 ½" CAP. 13 ½ oz



AMAZÔNIA 37004628

Copo 340 ml

Cup 340 ml

Vaso 340 ml

Gobelet 340 ml

△ 364 gr A 110 mm Ø 90 mm CAP. 340 ml

△ ½ lbs H 4 ½" Ø 3 ¾" CAP. 11 ½ oz



AMAZÔNIA 37004629

Copo 7 cl

Cup 7cl

Vaso 7 cl

Gobelet 7 cl

△ 100 gr A 65 mm Ø 60 mm CAP. 70 ml

△ ¾ lbs H 2 ½" Ø 2 ½" CAP. 2 ¾ oz



EXUBERANT



EXUBERANT 37003599
Prato Marcador 33
Charger Plate 33
Plato Presentación 33
Assiette de Présentation 33
△ 1070 gr A 25 mm C 325 mm L 310 mm
△ 2 ½ lbs H 1" L 12 ¼" W 12 ½"



EXUBERANT 37003598
Travessa Oval 39
Oval Platter 39
Fuente Oval 39
Plat Ovale 39
△ 1580 gr A 35 mm C 385 mm L 330 mm
△ 3 ½ lbs H 1 ⅜" L 15 ½" W 13"



EXUBERANT 37003562
Prato Raso 29
Dinner Plate 29
Plato Llano 29
Assiette Plate 29
△ 865 gr A 25 mm Ø 280 mm
△ 2 lbs H 1" Ø 11"



EXUBERANT 37003565
Prato Pasta 28
Pasta Plate 28
Plato Pasta 28
Assiette Pâtes 28
△ 830 gr A 45 mm C 280 mm L 270 mm CAP. 650 ml
△ 1 ⅝ lbs H 1 ⅞" L 11" W 10 ⅞" CAP. 22 oz



EXUBERANT 37005301
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 592 gr A 45 mm C 220 mm L 210 mm CAP. 550 ml
△ 1 ⅜ lbs H 1 ⅞" L 8 ⅜" W 8 ¼" CAP. 18 ⅜ oz

EXUBERANT



EXUBERANT 37003563

Prato Sobremesa 24

Dessert Plate 24

Plato Postre 24

Assiette Dessert 24

△ 471 gr A 25 mm C 235 mm L 230 mm

△ 1 lbs H 1" L 9 ¼" W 9"



EXUBERANT 37005299

Prato Pão 18

Bread & Butter Plate 18

Plato Pan 18

Assiette à Pain 18

△ 253 gr A 22 mm C 175 mm L 160 mm

△ 5/8 lbs H 7/8" L 6 8/9" W 6 2/7"



EXUBERANT 37003597

Saladeira 26

Salad Bowl 26

Ensaladera 26

Saladier 26

△ 1000 gr A 110 mm C 260 mm L 259 mm CAP. 1520 ml

△ 2 3/8 lbs H 4 1/8" L 10 1/4" W 9 3/8" CAP. 51 2/5 oz



EXUBERANT 37003564

Taça 17

Bowl 17

Taza 17

Bol 17

△ 400 gr A 55 mm C 170 mm L 155 mm CAP. 450 ml

△ 8/9 lbs H 2 1/8" L 6 2/8" W 6 1/8" CAP. 15 2/9 oz



EXUBERANT 37005300

Taça 11

Bowl 11

Taza 11

Bol 11

A 35 mm C 105 mm L 100 mm CAP. 70 ml

H 1 3/8" L 4 1/7" W 4" CAP. 2 3/8 oz



FLORAL SCENT



FLORAL SCENT 37006429

Travessa 30x16

Platter 30x16

Fuente 30x16

Plateau 30x16

△ 590 gr A 25 mm C 300 mm L 155 mm

△ 1 ½ lbs H 1" L 11 ¼" W 6 ½"



FLORAL SCENT 37006430

Travessa 25x14


Platter 25x14

Fuente 25x14

Plateau 25x14

△ 560 gr A 20 mm C 250 mm L 140 mm

△ 5 ¼ lbs H ¾" L 9 ⅝" W 5 ½"



FLORAL SCENT 37003555

Travessa Oval 39

Oval Platter 39

Fuente Oval 39

Plat Ovale 39

△ 1580 gr A 35 mm C 385 mm L 330 mm

△ 3 ⅞ lbs H 1 ⅜" L 15 ½" W 13"



FLORAL SCENT 37003548

Prato Marcador 33

Charger Plate 33

Plato Presentación 33

Assiette de Présentation 33

△ 1070 gr A 25 mm C 325 mm L 310 mm

△ 2 ½ lbs H 1" L 12 ¼" W 12 ½"



FLORAL SCENT 37006431

Travessa 20x10

Platter 20x10

Fuente 20x10

Plateau 20x10

△ 195 gr A 20 mm C 200 mm L 100 mm

△ ¾ lbs H ¼" L 7 ⅞" W 4"



FLORAL SCENT 37006416

Travessa Fruteiro

Fruit Platter

Fuente Frutera

Plateau de Fruits

△ 2160 gr A 52 mm C 400 mm

△ 4 ¾ lbs H 2" Ø 15 ¾"



FLORAL SCENT 37003549

Prato Raso 29

Dinner Plate 29

Plato Llano 29

Assiette Plate 29

△ 865 gr A 25 mm Ø 280 mm

△ 2 lbs H 1" Ø 11"

FLORAL SCENT



FLORAL SCENT 37005298

Prato Sopa 22

Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 592 gr A 45 mm C 220 mm L 210 mm CAP. 550 ml
△ 1 3/5 lbs H 1 7/8" L 8 3/8" W 8 1/4" CAP. 18 3/5 oz



FLORAL SCENT 37003552

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 830 gr A 45 mm C 280 mm L 270 mm CAP. 650 ml
△ 1 5/8 lbs H 1 7/8" L 11" W 10 5/8" CAP. 22 oz



FLORAL SCENT 37003554

Saladeira 26

Salad Bowl 26

Ensaladera 26

Saladier 26

A 110 mm C 260 mm L 250 mm CAP. 1520 ml
H 4 1/8" L 10 1/4" W 9 3/8" CAP. 51 3/5 oz



FLORAL SCENT 37003550


Prato Sobremesa 24

Dessert Plate 24

Plato Postre 24

Assiette Dessert 24

△ 471 gr A 25 mm C 235 mm L 230 mm
△ 1 lbs H 1" L 9 1/4" W 9"



FLORAL SCENT 37005296

Prato Pão 18

Bread & Butter Plate 18

Plato Pan 18

Assiette à Pain 18

△ 253 gr A 20 mm C 175 mm L 160 mm
△ 5/8 lbs H 7/8" L 6 5/8" W 6 3/8"



FLORAL SCENT 37005316

Tigela 20

Bowl 20

Taza 20

Bol 20

△ 750 gr A 70 mm C 200 mm L 190 mm CAP. 780 ml
△ 1 3/5 lbs H 2 3/4" L 7 7/8" W 7 1/2" CAP. 26 3/8 oz



FLORAL SCENT 37003551

Taça 17

Bowl 17

Taza 17

Bol 17

△ 400 gr A 55 mm C 170 mm L 155 mm CAP. 450 ml
△ 8/9 lbs H 2 1/8" L 6 3/8" W 6 1/8" CAP. 15 2/5 oz



FLORAL SCENT 37005297

Taça 11

Bowl 11

Taza 11

Bol 11

△ 146 gr A 35 mm C 105 mm L 100 mm CAP. 70 ml
△ 1/5 lbs H 1 3/8" L 4 1/2" W 4" CAP. 2 3/8 oz



FLORAL SCENT 37003553

Caneca 400 ml

Mug 400 ml

Jarra 400 ml

Tasse 400 ml

△ 366 gr A 110 mm C 120 mm L 90 mm CAP. 400 ml
△ 4/5 lbs H 4 1/8" L 4 3/8" W 3 1/2" CAP. 13 1/2 oz



FOLIAGE



FOLIAGE 37006121

Travessa 38


Platter 38

Fuente 38

Plat 38

△ 1580 gr A 35 mm C 380 mm L 305 mm

△ 3 ½ lbs H 1 ¾" L 15" W 12"



FOLIAGE 37006114

Travessa 24

Platter 24

Fuente 4

Plat 24

△ 523 gr A 23 mm C 239 mm L 190 mm

△ 1 ½ lbs H ¾" L 9 2/5" W 7 ½"



FOLIAGE 37006110

Prato Marcador 33


Charger Plate 33

Plato Presentación 33

Assiette à Présentation 33

△ 1111 gr A 25 mm C 325 mm

△ 2 ¾ lbs H 1" Ø 12 ¾"



FOLIAGE 37006120

Prato Raso 28

Dinner Plate 28

Plato Llano 28

Assiette Plate 28

△ 770 gr A 25 mm C 281 mm L 279 mm

△ 1 ½ lbs H 1" L 11 ½" W 11"

FOLIAGE



FOLIAGE 37006111
Prato Pasta 26
Pasta Plate 26
Plato Pasta 26
Assiette à Pâtes 26
△ 722 gr A 60 mm Ø 255 mm
△ 1 3/5 lbs H 2 3/8" Ø 10"



FOLIAGE 37006117
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 544 gr A 45 mm Ø 230 mm
△ 1 1/5 lbs H 1 7/8" Ø 9"



FOLIAGE 37006118
Prato Sobremesa 24
Dessert Plate 24
Plato Postre 24
Assiette Dessert 24
△ 485 gr A 25 mm C 235 mm L 230 mm
△ 1 1/5 lbs H 1" L 9 1/4" W 9"



FOLIAGE 37006113
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 253 gr A 22 mm C 179 mm L 172 mm
△ 5/8 lbs H 7/8" L 7" W 6 7/8"



FOLIAGE 37006116
Taça 17
Bowl 17
Taza 17
Bol 17
△ 400 gr A 55 mm C 155 mm L 170 mm
△ 7/8 lbs H 2 1/8" L 6 1/8" W 6 5/8"



FOLIAGE 37006115
Taça 11
Bowl 11
Taza 11
Bol 11
△ 146 gr A 35 mm C 105 mm L 100 mm
△ 1/5 lbs H 1 3/8" L 4 1/8" W 3 3/8"



FOLIAGE 37006119
Taça 11
Bowl 11
Taza 11
Bol 11
△ 146 gr A 35 mm C 105 mm L 100 mm
△ 1/5 lbs H 1 3/8" L 4 1/8" W 3 3/8"



FOLIAGE 37006112
Taça 12
Bowl 12
Taza 12
Bol 12
△ 341 gr A 50 mm C 120 mm
△ 3/4 lbs H 2" Ø 4 5/8"



FOLIAGE 37006122
Taça 12
Bowl 12
Taza 12
Bol 12
△ 341 gr A 50 mm Ø 120 mm
△ 3/4 lbs H 2" Ø 4 5/8"



GEMSTONE CORAL



GEMSTONE CORAL 210020817

Travessa Rectangular 36,5

Rectangular Platter 36,5

Fuente Rectangular 36,5

Plat Rectangulaire 36,5

△ 1100 gr A 30 mm C 365 mm L 170 mm

△ 2 3/8 lbs H 1 1/8" L 14 3/8" W 6 5/8"



GEMSTONE CORAL 210020815

Travessa Oval 27

Oval Platter 27

Fuente Oval 27

Plat Ovale 27

△ 800 gr A 45 mm C 270 mm L 200 mm

△ 1 3/4 lbs H 1 7/8" L 10 5/8" W 7 7/8"



GEMSTONE CORAL 210020839

Travessa Oval 34,5

Oval Platter 34,5

Fuente Oval 34,5

Plat Ovale 34,5

△ 960 gr A 45 mm C 345 mm L 170 mm

△ 2 1/8 lbs H 1 7/8" L 13 3/4" W 6 5/8"



GEMSTONE CORAL 210020819

Travessa Oval 30

Oval Platter 30

Fuente Oval 30

Plat Ovale 30

△ 900 gr A 30 mm C 300 mm L 150 mm

△ 2 lbs H 1 1/8" L 11 1/2" W 5 8/8"

GEMSTONE



GEMSTONE CORAL 210020833
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 900 gr A 25 mm Ø 280 mm
△ 2 lbs H 1" Ø 11"



GEMSTONE CORAL 210020835
Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22
△ 560 gr A 25 mm Ø 220 mm
△ 1 3/8 lbs H 1" Ø 8 3/8"



GEMSTONE CORAL 210020841
Prato Pão 16
Bread & Butter Plate 16
Plato Pan 16
Assiette à Pain 16
△ 280 gr A 20 mm Ø 160 mm
△ 5/8 lbs H 3/8" Ø 6 3/8"



GEMSTONE CORAL 210020837
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 760 gr A 25 mm Ø 220 mm CAP. 900 ml
△ 1 3/8 lbs H 1" Ø 8 3/8" CAP. 30 3/7 oz



GEMSTONE CORAL 210021087
Prato Fundo 23
Deep Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml
△ 1 1/2 lbs H 1 1/4" Ø 9" CAP. 30 3/7 oz



GEMSTONE CORAL 210020831
Prato Pasta 28
Pasta Plate 28
Plato Pasta 28
Assiette Pâtes 28
△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml
△ 2 1/3 lbs H 1 1/4" Ø 11" CAP. 44 oz

GEMSTONE



GEMSTONE CORAL 210020845

Taça 17

Bowl 17

Taza 17

Bol 17

△ 550 gr A 76 mm Ø 170 mm

△ 1 3/8 lbs H 3" Ø 6 5/8"



GEMSTONE CORAL 210020853

Taça 16

Bowl 16

Taza 16

Bol 16

△ 390 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 8/9 lbs H 1 7/8" Ø 6 1/2" CAP. 21 3/8 oz



GEMSTONE CORAL 210020843

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm Ø 155 mm CAP. 630 ml

△ 8/9 lbs H 2 3/4" Ø 6 1/8" CAP. 21 1/3 oz



GEMSTONE CORAL 210020847

Taça 12

Bowl 12

Taza 12

Bol 12

△ 220 gr A 55 mm Ø 120 mm CAP. 350 ml

△ 1/2 lbs H 2 1/8" Ø 4 5/8" CAP. 11 5/8 oz



GEMSTONE CORAL 210020849

Taça 9

Bowl 9

Taza 9

Bol 9

△ 100 gr A 40 mm Ø 85 mm CAP. 100 ml

△ 3/8 lbs H 1 1/2" Ø 3 1/3" CAP. 3 3/8 oz



GEMSTONE CORAL 210020851

Pires

Saucer

Platillo

Sous-Gobelet

△ 250 gr A 20 mm Ø 140 mm

△ 5/8 lbs H 7/9" Ø 5 1/2"



GEMSTONE CORAL 210020859

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 2/8" Ø 3 3/8" CAP. 11 5/8 oz



GEMSTONE CORAL 210020857

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 3/8" Ø 3 1/3" CAP. 8 4/8 oz



GEMSTONE CORAL 210020855

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/8 lbs H 2 3/4" Ø 2 1/4" CAP. 2 3/8 oz

GEMSTONE JADE



GEMSTONE JADE 210019955

Travessa Retangular 36,5

Rectangular Platter 36,5

Fuente Rectangular 36,5

Plat Rectangulaire 36,5

△ 1100 gr A 30 mm C 365 mm L 170 mm

△ 2 3/8 lbs H 1 1/8" L 14 3/8" W 6 5/8"



GEMSTONE JADE 210019959

Travessa Oval 27

Oval Platter 27

Fuente Oval 27

Plat Ovale 27

△ 800 gr A 45 mm C 270 mm L 200 mm

△ 1 3/4 lbs H 1 7/8" L 10 5/8" W 7 7/8"



GEMSTONE JADE 210019953

Travessa Oval 34,5

Oval Platter 34,5

Fuente Oval 34,5

Plat Ovale 34,5

△ 960 gr A 45 mm C 345 mm L 170 mm

△ 2 1/8 lbs H 1 7/8" L 13 3/4" W 6 5/8"



GEMSTONE JADE 210019939

Travessa Oval 30

Oval Platter 30

Fuente Oval 30

Plat Ovale 30

△ 900 gr A 30 mm C 300 mm L 150 mm

△ 2 lbs H 1 1/8" L 11 1/2" W 5 7/8"

GEMSTONE



GEMSTONE JADE 210019945

Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28

△ 900 gr A 25 mm Ø 280 mm
△ 2 lbs H 1" Ø 11"



GEMSTONE JADE 210019947

Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22


△ 560 gr A 25 mm Ø 220 mm
△ 1 3/8 lbs H 1" Ø 8 3/8"



GEMSTONE JADE 210019949

Prato Pão 16
Bread & Butter Plate 16
Plato Pan 16
Assiette à Pain 16

△ 280 gr A 20 mm Ø 160 mm
△ 5/8 lbs H 7/8" Ø 6 3/4"



GEMSTONE JADE 210019951

Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22

△ 760 gr A 25 mm Ø 220 mm CAP. 900 ml
△ 1 3/8 lbs H 1" Ø 8 3/8" CAP. 30 3/7 oz



GEMSTONE JADE 210021089

Prato Fundo 23
Deep Plate 23
Plato Hondo 23
Assiette Creuse 23

△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml
△ 1/2 lbs H 1 1/4" Ø 9" CAP. 30 3/7 oz



GEMSTONE JADE 210019964

Prato Pasta 28
Pasta Plate 28
Plato Pasta 28
Assiette Pâtes 28

△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml
△ 2 1/8 lbs H 1 1/4" Ø 11" CAP. 44 oz

GEMSTONE



GEMSTONE JADE 210020131

Taça 17

Bowl 17

Taza 17

Bol 17

△ 550 gr A 76 mm Ø 170 mm

△ 1 3/8 lbs H 3" Ø 6 5/8"



GEMSTONE JADE 210019943

Taça 16

Bowl 16

Taza 16

Bol 16

△ 390 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 8/9 lbs H 1 7/8" Ø 6 1/2" CAP. 21 3/8 oz



GEMSTONE JADE 210019957

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm Ø 155 mm CAP. 630 ml

△ 8/9 lbs H 2 3/4" Ø 6 1/8" CAP. 21 1/3 oz



GEMSTONE JADE 210020135

Taça 12

Bowl 12

Taza 12

Bol 12

△ 220 gr A 55 mm Ø 120 mm CAP. 350 ml

△ 1/2 lbs H 2 1/8" Ø 4 5/8" CAP. 11 5/8 oz



GEMSTONE JADE 210020139

Taça 9

Bowl 9

Taza 9

Bol 9

△ 100 gr A 40 mm Ø 85 mm CAP. 100 ml

△ 3/8 lbs H 1 1/8" Ø 3 1/3" CAP. 3 3/8 oz



GEMSTONE JADE 210020143

Pires

Saucer

Platillo

Sous-Gobelet

△ 250 gr A 20 mm Ø 140 mm

△ 5/8 lbs H 7/9" Ø 5 1/2"



GEMSTONE JADE 210020155

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 3/8" Ø 3 3/8" CAP. 11 5/8 oz



GEMSTONE JADE 210020151

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 3/8" Ø 3 1/3" CAP. 8 4/8 oz



GEMSTONE JADE 210020147

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/8 lbs H 2 3/4" Ø 2 1/4" CAP. 2 3/8 oz

GEMSTONE



GEMSTONE LÁPIS LAZULI



GEMSTONE LÁPIS LAZULI

210020019

Travessa Retangular 36,5
Rectangular Platter 36,5
Fuente Rectangular 36,5
Plat Rectangulaire 36,5

△ 1100 gr A 30 mm C 365 mm L 170 mm

△ 2 3/8 lbs H 1 1/8" L 14 3/8" W 6 5/8"



GEMSTONE LÁPIS LAZULI 210020015

Travessa Oval 27

Oval Platter 27

Fuente Oval 27

Plat Ovale 27

△ 800 gr A 45 mm C 270 mm L 200 mm

△ 1 3/4 lbs H 1 7/8" L 10 5/8" W 7 7/8"



GEMSTONE LÁPIS LAZULI 210020052

Travessa Oval 34,5

Oval Platter 34,5

Fuente Oval 34,5

Plat Ovale 34,5

△ 960 gr A 45 mm C 345 mm L 170 mm

△ 2 1/8 lbs H 1 7/8" L 13 4/8" W 6 5/8"



GEMSTONE LÁPIS LAZULI 210020041

Travessa Oval 30

Oval Platter 30

Fuente Oval 30

Plat Ovale 30

△ 900 gr A 30 mm C 300 mm L 150 mm

△ 2 lbs H 1 1/8" L 11 1/8" W 5 3/8"

GEMSTONE



GEMSTONE LÁPIS LAZULI

210020017

Prato Raso 28

Dinner Plate 28

Plato Llano 28

Assiette Plate 28

△ 900 gr A 25 mm Ø 280 mm

△ 2 lbs H 1" Ø 11"



GEMSTONE LÁPIS LAZULI

210020048

Prato Sobremesa 22

Dessert Plate 22

Plato Postre 22

Assiette Dessert 22

△ 560 gr A 25 mm Ø 220 mm

△ 1 3/8 lbs H 1" Ø 8 3/4"



GEMSTONE LÁPIS LAZULI

210020054

Prato Pão 16

Bread & Butter Plate 16

Plato Pan 16

Assiette à Pain 16

△ 280 gr A 20 mm Ø 160 mm

△ 5/8 lbs H 7/8" Ø 6 3/4"



GEMSTONE LÁPIS LAZULI

210020050

Prato Sopa 22

Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 760 gr A 25 mm Ø 220 mm CAP. 900 ml

△ 1 3/8 lbs H 1" Ø 8 3/4" CAP. 30 3/4 oz



GEMSTONE LÁPIS LAZULI

210021095

Prato Fundo 23

Deep Plate 23

Plato Hondo 23

Assiette Creuse 23

△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml

△ 1 1/2 lbs H 1 1/4" Ø 9" CAP. 30 3/4 oz



GEMSTONE LÁPIS LAZULI

210020043

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml

△ 2 1/2 lbs H 1 1/4" Ø 11" CAP. 44 oz

GEMSTONE



GEMSTONE LÁPIS LAZULI

210020133

Taça 17

Bowl 17

Taza 17

Bol 17

△ 550 gr A 76 mm Ø 170 mm CAP. 1000 ml

△ 1 3/8 lbs H 3" Ø 6 3/4" CAP. 33 4/5 oz



GEMSTONE LÁPIS LAZULI

210020035

Taça 16

Bowl 16

Taza 16

Bol 16

△ 390 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 5/8 lbs H 1 7/8" Ø 6 1/2" CAP. 15 3/8 oz



GEMSTONE LÁPIS LAZULI

210020031

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm C 155 mm CAP. 630 ml

△ 3/4 lbs H 2 3/4" L 6 1/8" CAP. 21 1/2 oz



GEMSTONE LÁPIS LAZULI

210020137

Taça 12

Bowl 12

Taza 12

Bol 12

△ 220 gr A 55 mm C 120 mm CAP. 350 ml

△ 1/2 lbs H 2 1/8" L 4 5/8" CAP. 11 5/8 oz



GEMSTONE LÁPIS LAZULI

210020141

Taça 9

Bowl 9

Taza 9

Bol 9

△ 100 gr A 40 mm Ø 85 mm CAP. 100 ml

△ 3/8 lbs H 1 1/2" Ø 3 1/2" CAP. 3 3/8 oz



GEMSTONE LÁPIS LAZULI

210020145

Pires

Saucer

Platillo

Sous-Gobelet

△ 250 gr A 20 mm C 140 mm

△ 5/8 lbs H 7/9" L 5 1/2"



GEMSTONE LÁPIS LAZULI

210020157

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 3/8" Ø 3 3/8" CAP. 11 5/8 oz



GEMSTONE LÁPIS LAZULI

210020153

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 5/8" Ø 3 1/2" CAP. 8 4/8 oz



GEMSTONE LÁPIS LAZULI

210020149

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/8 lbs H 2 3/4" Ø 2 1/4" CAP. 2 3/8 oz

GEMSTONE



GEMSTONE MOONSTONE



GEMSTONE MOONSTONE 210020416

Travessa Retangular 36,5
Rectangular Platter 36,5
Fuente Rectangular 36,5
Plat Rectangulaire 36,5

△ 1100 gr A 30 mm C 365 mm L 170 mm
△ 2 3/8 lbs H 1 1/8" L 14 3/8" W 6 5/8"



GEMSTONE MOONSTONE 210020414

Travessa Oval 27
Oval Platter 27
Fuente Oval 27
Plat Ovale 27

△ 800 gr A 45 mm C 270 mm L 200 mm
△ 1 3/4 lbs H 1 7/8" L 10 3/8" W 7 7/8"



GEMSTONE MOONSTONE 210020428

Travessa Oval 34,5
Oval Platter 34,5
Fuente Oval 34,5
Plat Ovale 34,5

△ 960 gr A 45 mm C 345 mm L 170 mm
△ 2 1/8 lbs H 1 7/8" L 13 4/8" W 6 5/8"



GEMSTONE MOONSTONE 210020418

Travessa Oval 30
Oval Platter 30
Fuente Oval 30
Plat Ovale 30

△ 900 gr A 30 mm C 300 mm L 150 mm
△ 2 lbs H 1 1/8" L 11 3/8" W 5 8/8"

GEMSTONE



GEMSTONE MOONSTONE

210020422

Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28

△ 900 gr A 25 mm Ø 280 mm

△ 2 lbs H 1" L 11"



GEMSTONE MOONSTONE

210020424

Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22

△ 560 gr A 25 mm Ø 220 mm

△ 1 3/8 lbs H 1" Ø 8 3/8"



GEMSTONE MOONSTONE

210020430

Prato Pão 16
Bread & Butter Plate 16
Plato Pan 16
Assiette à Pain 16

△ 280 gr A 20 mm Ø 160 mm

△ 3/8 lbs H 7/8" L 6 3/8"



GEMSTONE MOONSTONE

210020426

Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22

△ 760 gr A 25 mm Ø 220 mm CAP. 900 ml

△ 1 3/8 lbs H 1" Ø 8 3/8" CAP. 30 3/8 oz



GEMSTONE MOONSTONE

210021085

Prato Fundo 23
Deep Plate 23
Plato Hondo 23
Assiette Creuse 23

△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml

△ 1/2 lbs H 1 1/2" Ø 9" CAP. 30 3/8 oz



GEMSTONE MOONSTONE

210020420

Prato Pasta 28
Pasta Plate 28
Plato Pasta 28
Assiette Pâtes 28

△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml

△ 2 1/8 lbs H 1 1/4" Ø 11" CAP. 44 oz

GEMSTONE



GEMSTONE MOONSTONE

210020434

Taça 17

Bowl 17

Taza 17

Bol 17

△ 550 gr A 76 mm Ø 170 mm CAP. 1000 ml

△ 1 3/8 lbs H 3" Ø 6 3/4" CAP. 33 4/5 oz



GEMSTONE MOONSTONE

210020443

Taça 16

Bowl 16

Taza 16

Bol 16

△ 390 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 5/8 lbs H 1 7/8" Ø 6 1/2" CAP. 15 3/8 oz



GEMSTONE MOONSTONE

210020432

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm Ø 155 mm CAP. 630 ml

△ 9/8 lbs H 2 3/4" Ø 6 1/8" CAP. 21 1/3 oz



GEMSTONE MOONSTONE

210020437

Taça 12

Bowl 12

Taza 12

Bol 12

△ 220 gr A 55 mm Ø 120 mm CAP. 350 ml

△ 1/2 lbs H 2 1/8" Ø 4 3/4" CAP. 11 5/8 oz



GEMSTONE MOONSTONE

210020439

Taça 9

Bowl 9

Taza 9

Bol 9

△ 100 gr A 40 mm Ø 85 mm CAP. 100 ml

△ 3/8 lbs H 1 1/2" Ø 3 1/2" CAP. 3 3/8 oz



GEMSTONE MOONSTONE

210020441

Pires

Saucer

Platillo

Sous-Gobelet

△ 250 gr A 20 mm Ø 140 mm

△ 5/8 lbs H 7/9" Ø 5 1/2"



GEMSTONE MOONSTONE

210020449

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 3/8" Ø 3 3/4" CAP. 11 5/8 oz



GEMSTONE MOONSTONE

210020447

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 5/8" Ø 3 1/2" CAP. 8 4/8 oz



GEMSTONE MOONSTONE

210020445

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/8 lbs H 2 3/4" Ø 2 1/4" CAP. 2 3/8 oz

GEMSTONE





GOLD STONE



GOLD STONE 37006418
 Travessa Fruteiro
 Fruit Platter
 Fuente Frutera
 Plateau de Fruits
 A 52 mm Ø 400 mm
 H 2" Ø 15 3/4"



GOLD STONE 37006417
 Travessa Fruteiro
 Fruit Platter
 Fuente Frutera
 Plateau de Fruits
 A 52 mm Ø 400 mm
 H 2" Ø 15 3/4"



GOLD STONE 37006436
 Travessa 30x16
 Platter 30x16
 Fuente 30x16
 Plateau 30x16
 △ 590 gr A 25 mm C 300 mm L 155 mm
 △ 1 1/2 lbs H 1" L 11 4/5" W 6 1/8"



GOLD STONE 37006437
 Travessa 25x14
 Platter 25x14
 Fuente 25x14
 Plateau 25x14
 △ 560 gr A 20 mm C 250 mm L 140 mm
 △ 5 1/4 lbs H 4/5" L 9 3/8" W 5 1/2"



GOLD STONE 37006438
 Travessa 20x10
 Platter 20x10
 Fuente 20x10
 Plateau 20x10
 △ 195 gr A 20 mm C 200 mm L 100 mm
 △ 3/7 lbs H 4/5" L 7 7/8" W 4"



GOLD STONE 37006439
 Travessa 30x16
 Platter 30x16
 Fuente 30x16
 Plateau 30x16
 △ 590 gr A 25 mm C 300 mm L 155 mm
 △ 1 1/2 lbs H 1" L 11 4/5" W 6 1/8"



GOLD STONE 37006440
 Travessa 25x14
 Platter 25x14
 Fuente 25x14
 Plateau 25x14
 △ 560 gr A 20 mm C 250 mm L 140 mm
 △ 5 1/4 lbs H 4/5" L 9 3/8" W 5 1/2"



GOLD STONE 37006441
 Travessa 20x10
 Platter 20x10
 Fuente 20x10
 Plateau 20x10
 △ 195 gr A 20 mm C 200 mm L 100 mm
 △ 3/7 lbs H 4/5" L 7 7/8" W 4"

GOLD STONE



GOLD STONE 37004096
 Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41

△ 2415 gr A 55 mm C 410 mm
 △ 5 ½ lbs H 2 ¼" L 16 ½"



GOLD STONE 37004095
 Travessa Oval 41
Oval Platter 41
Fuente Oval 41
Plat Ovale 41

△ 1358 gr A 30 mm C 405 mm L 260 mm
 △ 3 lbs H 1 ½" L 16" W 10 ¼"



GOLD STONE 37004083
 Prato Marcador 34
Charger Plate 34
Plato Presentación 34
Assiette de Présentation 34

△ 1111 gr A 35 mm Ø 335 mm
 △ 2 ⅘ lbs H 1 ⅜" Ø 13 ⅓"



GOLD STONE 37006088
 Prato Marcador 34
Charger Plate 34
Plato Presentación 34
Assiette de Présentation 34

△ 1111 gr A 35 mm Ø 335 mm
 △ 2 ⅘ lbs H 1 ⅜" Ø 13 ⅓"



GOLD STONE 37004663
 Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28

△ 835 gr A 25 mm Ø 275 mm
 △ 1 ⅝ lbs H 1" Ø 10 ⅝"



GOLD STONE 37006101
 Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28

△ 835 gr A 25 mm Ø 275 mm
 △ 1 ⅝ lbs H 1" Ø 10 ⅝"

GOLD STONE



GOLD STONE 37004076
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 592 gr A 45 mm Ø 220 mm CAP. 550 ml
△ 1 ½ lbs H 1 7/8" Ø 8 ¼" CAP. 18 ¾ oz



GOLD STONE 37004664
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 45 mm Ø 230 mm CAP. 360 ml
△ 1 ½ lbs H 1 7/8" Ø 9" CAP. 12 ½ oz



GOLD STONE 37006104
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 45 mm Ø 230 mm CAP. 360 ml
△ 1 ½ lbs H 1 7/8" Ø 9" CAP. 12 ½ oz



GOLD STONE 37004665
Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22
△ 544 gr A 25 mm Ø 220 mm
△ 1 ½ lbs H 1" Ø 8 ¾"



GOLD STONE 37006102
Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22
△ 544 gr A 25 mm Ø 220 mm
△ 1 ½ lbs H 1" Ø 8 ¾"



GOLD STONE 37004087
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 346 gr A 25 mm Ø 175 mm
△ ¾ lbs H 1" Ø 6 ¾"



GOLD STONE 37006103
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 346 gr A 25 mm Ø 175 mm
△ ¾ lbs H 1" Ø 6 ¾"



GOLD STONE 37004094
Saladeira 27
Salad Bowl 27
Ensaladera 27
Saladier 27
△ 1175 gr A 110 mm Ø 265 mm CAP. 1780 ml
△ 2 ¾ lbs H 4 ½" Ø 10 ¾" CAP. 60 ½ oz



GOLD STONE 37004078
Saladeira 26
Salad Bowl 26
Ensaladera 26
Saladier 26
△ 1000 gr A 110 mm C 260 mm
L 250 mm CAP. 1520 ml
△ 2 ¾ lbs H 4 ½" L 10 ¼" W 9 ¾" CAP. 51 ¾ oz

GOLD STONE



GOLD STONE 37004088

Prato Pasta 26

Pasta Plate 26

Plato Pasta 26

Assiette Pâtes 26

△ 722 gr A 60 mm Ø 255 mm CAP. 1225 ml

△ 1 3/5 lbs H 2 1/2" Ø 10" CAP. 41 3/7 oz



GOLD STONE 37006105

Prato Pasta 26

Pasta Plate 26

Plato Pasta 26

Assiette Pâtes 26

△ 722 gr A 60 mm Ø 255 mm CAP. 1225 ml

△ 1 3/5 lbs H 2 1/2" Ø 10" CAP. 41 3/7 oz



GOLD STONE 37004077

Taça 17

Bowl 17

Taza 17

Bol 17

△ 400 gr A 55 mm C 170 mm

L 155 mm CAP. 450 ml

△ 7/8 lbs H 2 1/8" L 6 3/8" W 6 1/8" CAP. 15 3/8 oz



GOLD STONE 37004089

Taça 16

Bowl 16

Taza 16

Bol 16

△ 341 gr A 75 mm Ø 160 mm CAP. 560 ml

△ 3/4 lbs H 3" Ø 6 3/7" CAP. 19 oz



GOLD STONE 37004092

Taça 12

Bowl 12

Taza 12

Bol 12

△ 176 gr A 50 mm Ø 120 mm CAP. 185 ml

△ 3/5 lbs H 2" Ø 4 5/7" CAP. 6 1/4 oz



GOLD STONE 37004079

Taça 10

Bowl 10

Taza 10

Bol 10

△ 146 gr A 35 mm C 105 mm L 100 mm CAP. 70 ml

△ 2/5 lbs H 1 3/8" L 4 1/7" W 4" CAP. 2 3/8 oz



GOLD STONE 37004093

Copo 7 cl

Cup 7 cl

Vaso 7 cl

Gobelet 7 cl

△ 100 gr A 65 mm Ø 60 mm CAP. 70 ml

△ 2/5 lbs H 2 3/8" Ø 2 1/2" CAP. 2 3/8 oz



GOLD STONE 37004082

Copo 7 cl

Cup 7 cl

Vaso 7 cl

Gobelet 7 cl

△ 100 gr A 65 mm Ø 60 mm CAP. 70 ml

△ 2/5 lbs H 2 3/8" Ø 2 1/2" CAP. 2 3/8 oz



GOLD STONE 37004090

Caneca 340 ml

Mug 340 ml

Jarra 340 ml

Mug 340 ml

△ 384 gr A 110 mm C 130 mm

L 90 mm CAP. 340 ml

△ 6/5 lbs H 4 1/2" L 5 1/8" W 3 1/2" CAP. 11 1/2 oz



IMPERFECT WHITE



IMPERFECT WHITE 37004726

Travessa Oval 40

Oval Platter 40

Fuente Oval 40

Plat Ovale 40

△ 1582 gr A 40 mm C 400 mm L 280 mm

△ 3 ½ lbs H 1 ¼" L 15 ¾" W 11"



IMPERFECT WHITE 37004715

Prato Marcador 33

Charger Plate 33

Plato Presentación 33

Assiette de Présentation 33

△ 1245 gr A 20 mm Ø 330 mm

△ 2 ¾ lbs H 7/8" Ø 13"



IMPERFECT WHITE 37004727

Prato Raso 27

Dinner Plate 27

Plato Llano 27

Assiette Plate 27

△ 646 gr A 25 mm Ø 265 mm

△ 2 ¾ lbs H 1" Ø 10 ¾"



IMPERFECT WHITE 37005056

Prato Sopa 22

Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 505 gr A 45 mm Ø 215 mm CAP. 450 ml

△ 1 ⅓ lbs H 1 7/8" Ø 8 ½" CAP. 15 ¾ oz



IMPERFECT WHITE 37004728

Prato Sobremesa 23

Dessert Plate 23

Plato Postre 23

Assiette Dessert 23

△ 422 gr A 20 mm Ø 225 mm

△ 1 lbs H 7/8" Ø 8 7/8"

IMPERFECT WHITE



IMPERFECT WHITE 37004729

Saladeira 25
Salad Bowl 25
Ensaladera 25
Saladier 25

△ 1101 gr A 105 mm Ø 250 mm CAP. 2000 ml
△ 2 3/4 lbs H 4 1/8" Ø 9 3/4" CAP. 67 3/8 oz



IMPERFECT WHITE 37004731

Taça 16
Bowl 16
Taza 16
Bol 16

△ 400 gr A 75 mm Ø 160 mm CAP. 500 ml
△ 7/8 lbs H 3" Ø 6 3/4" CAP. 16 5/8 oz



IMPERFECT WHITE 37004730

Caneca 370 ml
Mug 370 ml
Jarra 370 ml
Tasse 370 ml

△ 270 gr A 120 mm C 140 mm L 95 mm CAP. 370 ml
△ 4/5 lbs H 4 3/4" L 5 1/2" W 3 3/4" CAP. 12 1/2 oz



IRIS



IRIS 37003749
Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41
△ 2415 gr A 55 mm Ø 410 mm
△ 5 ½ lbs H 2 ¼" Ø 16 ½"



IRIS 37003748
Travessa Oval 41
Oval Platter 41
Fuente Oval 41
Plat Ovale 41
△ 1358 gr A 30 mm C 405 mm L 260 mm
△ 3 lbs H 1 ½" L 16" W 10 ¼"



IRIS 37003736
Prato Marcador 34
Charger Plate 34
Plato Presentación 34
Assiette de Présentation 34
△ 1111 gr A 35 mm Ø 335 mm
△ 2 ¼ lbs H 1 ¾" Ø 13 ½"



IRIS 37004594
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 835 gr A 25 mm Ø 275 mm
△ 1 ¾ lbs H 1" Ø 10 ¾"



IRIS 37003741
Prato Pasta 26
Pasta Plate 26
Plato Pasta 26
Assiette Pâtes 26
△ 722 gr A 60 mm Ø 255 mm CAP. 1225 ml
△ 1 ¾ lbs H 2 ¾" Ø 10" CAP. 41 ¾ oz

IRIS



IRIS 37004595
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 45 mm Ø 230 mm CAP. 360 ml
△ 1 ½ lbs H 1 7/8" Ø 9" CAP. 12 ½ oz



IRIS 37004656
Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22
△ 544 gr A 25 mm Ø 220 mm
△ 1 ½ lbs H 1" Ø 8 3/4"



IRIS 37003740
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 346 gr A 25 mm Ø 175 mm
△ 3/4 lbs H 1" Ø 6 3/4"



IRIS 37003747
Saladeira 27
Salad Bowl 27
Ensaladera 27
Saladier 27
△ 1175 gr A 110 mm Ø 265 mm CAP. 1780 ml
△ 2 3/5 lbs H 4 1/2" Ø 10 3/4" CAP. 60 1/2 oz



IRIS 37003742
Taça 16
Bowl 16
Taza 16
Bol 16
△ 448 gr A 68 mm Ø 162 mm CAP. 625 ml
△ 1 lbs H 2 3/8" Ø 6 1/2" CAP. 21 1/2 oz



IRIS 37003743
Taça Cônica 16
Bowl 16
Cuenco 16
Bol 16
△ 341 gr A 75 mm Ø 160 mm CAP. 560 ml
△ 3/4 lbs H 3" Ø 6 3/4" CAP. 18 3/4 oz



IRIS 37003746
Taça 12
Bowl 12
Taza 12
Bol 12
△ 176 gr A 50 mm Ø 120 mm CAP. 185 ml
△ 3/5 lbs H 2" Ø 4 5/8" CAP. 6 1/4 oz



IRIS 37003744
Caneca 340 ml
Mug 340 ml
Jarra 340 ml
Tasse 340 ml
△ 384 gr A 110 mm C 130 mm L 90 mm CAP. 340 ml
△ 6/7 lbs H 4 1/2" L 5 1/8" W 3 5/8" CAP. 11 1/2 oz



NORDIC IRON



NORDIC IRON 210020199

Prato Raso 27
Dinner Plate 27
Plato Llano 27
Assiette Plate 27

△ 1200 gr A 21 mm Ø 275 mm
△ 2 5/8 lbs H 5/8" Ø 10 3/4"



NORDIC IRON 210020193

Prato Sobremesa 22
Dessert Plate 22
Plato Postre 22
Assiette Dessert 22

△ 700gr A 20 mm Ø 216 mm
△ 1 5/8 lbs H 7/8" Ø 8 1/2"



NORDIC IRON 210020192

Prato Pão 15
Bread & Butter Plate 15
Plato Pan 15
Assiette à Pain 15

△ 380 gr A 19 mm Ø 153 mm
△ 5/8 lbs H 3/4" Ø 6"



NORDIC IRON 210020197

Prato 10
Plate 10
Plato 10
Assiette 10

△ 160 gr A 16 mm Ø 100 mm
△ 1/3 lbs H 5/8" Ø 4"

NORDIC IRON



NORDIC IRON 210020194

Taça 21

Bowl 21

Taza 21

Bol 21

△ 920 gr A 44 mm Ø 214 mm

△ 2 lbs H 1 ¾" Ø 8 ½"



NORDIC IRON 210020191

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 680 gr A 19 mm Ø 152 mm

△ 1 ½ lbs H ¾" Ø 6"



NORDIC IRON 210020412

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 ¾" Ø 3 ¾" CAP. 11 5/8 oz



NORDIC IRON 210020196

Taça 12

Bowl 12

Taza 12

Bol 12

△ 460 gr A 60 mm Ø 121 mm

△ 1 lbs H 2 ¾" Ø 4 ¾"



NORDIC IRON 210020195

Taça 6

Bowl 6

Taza 6

Bol 6

△ 100 gr A 30 mm Ø 63 mm

△ 3/8 lbs H 1 1/8" Ø 2 1/2"



NORDIC IRON 210020410

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 5/8" Ø 3 1/8" CAP. 8 5/8 oz



NORDIC IRON 210020198

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/5 lbs H 2 ¾" Ø 2 ¼" CAP. 2 2/3 oz

Indisponível nos EUA e Canadá.
Not available for USA and Canada.
No disponible en Estados Unidos y Canadá.
Non disponible aux États-Unis et au Canada.

QUÉOPS



QUÉOPS 37006413
Travessa Oval 40
Oval Platter 40
Fuente Oval 40
Plateau Ovale 40
△ 1358 gr A 30 mm C 405 mm L 260 mm
△ 3 lbs H 1 1/8" L 16" W 10 1/4"



QUÉOPS 37006135
Travessa Oval 45
Oval Platter 45
Fuente Oval 45
△ 715 gr A 17 mm C 131 mm L 452 mm
△ 1 4/5 lbs H 2/5" L 5 1/2" W 17 4/5"



QUÉOPS 37006133
Travessa Redonda 40
Round Plate 40
Fuente Redonda 40
Plat à Servir Rond 40
△ 2415 gr A 55 mm Ø 410 mm
△ 5 1/3 lbs H 2 1/8" Ø 16 1/2"



QUÉOPS 37006415
Travessa Retangular 32
Rectangular Platter 32
Fuente Rectangular 32
Plateau Rectangulaire 32
△ 1300 gr A 19 mm C 322 mm L 224 mm
△ 2 5/8" H 3/4" L 12 2/3" W 8 5/8"



QUÉOPS 37006132
Prato Marcador 32
Charger Plate 32
Plato Presentación 32
Assiette Présentation 32
△ 1111 gr A 35 mm Ø 325 mm
△ 2 4/5 lbs H 1 3/8" Ø 13 1/2"

QUÉOPS



QUÉOPS 37006406
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 870 gr A 25 mm Ø 275 mm
△ 2 lbs H 1" Ø 10 3/8"



QUÉOPS 37006414
Prato Pasta 26
Pasta Plate 26
Plato Pasta 26
Assiette Pâtes 26
△ 875 gr A 60 mm Ø 255 mm CAP. 1225 ml
△ 2 lbs H 2 3/8" Ø 10" CAP. 41 3/5 oz



QUÉOPS 37006408
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 45 mm Ø 230 mm CAP. 360 ml
△ 1 1/2 lbs H 1 7/8" Ø 9" CAP. 12 1/2 oz



QUÉOPS 37006407
Prato Sobremesa 22
Dessert Plate 22
Plato Pastre 22
Assiette Dessert 22
△ 544 gr A 25 mm Ø 220 mm
△ 1 1/5 lbs H 1" Ø 8 3/8"



QUÉOPS 37006136
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 346 gr A 25 mm Ø 175 mm
△ 3/4 lbs H 1" Ø 6 3/8"



QUÉOPS 37006411
Saladeira 27
Salad Bowl 27
Ensaladera 27
Saladier 27
△ 1175 gr A 110 mm Ø 265 mm CAP. 1780 ml
△ 2 3/5 lbs H 4 1/8" Ø 10 3/8" CAP. 60 1/5 oz



QUÉOPS 337006409
Taça 16
Bowl 16
Cuenco 16
Bol 16
△ 341 gr A 75 mm Ø 160 mm CAP. 560 ml
△ 3/4 lbs H 3" Ø 6 2/8" CAP. 18 3/8 oz



QUÉOPS 37006412
Taça 12
Bowl 12
Taza 12
Bol 12
△ 176 gr A 50 mm Ø 120 mm CAP. 185 ml
△ 2/5 lbs H 2" Ø 4 5/8" CAP. 6 1/4 oz



QUÉOPS 37006410
Copo 340 ml
Cup 340 ml
Vaso 340 ml
Tasse 340 ml
△ 364 gr A 110 mm C 130 mm L 90 mm CAP. 340 ml
△ 4/5 lbs H 4 1/8" L 5 1/8" W 3 5/8" CAP. 11 1/2 oz



RUSTIC BLEND



RUSTIC BLEND 27020966
 Travessa Oval 35
 Oval Platter 35
 Fuente Oval 35
 Plat Ovale 35
 △ 970 gr A 45 mm C 345 mm L 170 mm
 △ 2 1/2 lbs H 1 7/8" L 13 4/8" W 6 3/8"



RUSTIC BLEND 27020974
 Travessa Oval 35
 Oval Platter 35
 Fuente Oval 35
 Plat Ovale 35
 △ 970 gr A 45 mm C 345 mm L 170 mm
 △ 2 1/2 lbs H 1 7/8" L 13 4/8" W 6 3/8"



RUSTIC BLEND 27020960
 Travessa Oval 30
 Oval Platter 30
 Fuente Oval 30
 Plat Ovale 30
 △ 900 gr A 30 mm Ø 300 mm L 150 mm
 △ 2 lbs H 1 1/8" Ø 11 4/8" W 6"



RUSTIC BLEND 27020970
 Travessa Oval 30
 Oval Platter 30
 Fuente Oval 30
 Plat Ovale 30
 △ 900 gr A 30 mm Ø 300 mm L 150 mm
 △ 2 lbs H 1 1/8" Ø 11 4/8" W 6"



RUSTIC BLEND 27020968
 Travessa Oval 27
 Oval Platter 27
 Fuente Oval 27
 Plat Ovale 27
 △ 800 gr A 45 mm C 270 mm L 200 mm
 △ 1 3/4 lbs H 1 7/8" L 10 5/8" W 7 7/8"



RUSTIC BLEND 27020958
 Travessa Oval 27
 Oval Platter 27
 Fuente Oval 27
 Plat Ovale 27
 △ 800 gr A 45 mm C 270 mm L 200 mm
 △ 1 3/4 lbs H 1 7/8" L 10 5/8" W 7 7/8"



RUSTIC BLEND 27020963
 Prato Raso 28
 Dinner Plate 28
 Plato Llano 28
 Assiette Plate 28
 △ 900 gr A 25 mm Ø 280 mm
 △ 2 lbs H 1" Ø 11"

RUSTIC BLEND



RUSTIC BLEND 27020969

Travessa Retangular 37


Rectangular Platter 37

Fuente Rectangular 37

Plat Rectangulaire 37

△ 1100 gr A 30 mm C 365 mm L 170 mm

△ 2 3/7 lbs H 1 1/8" L 14 3/8" W 6 3/8"



RUSTIC BLEND 27020959

Travessa Retangular 37

Rectangular Platter 37

Fuente Rectangular 37

Plat Rectangulaire 37

△ 1100 gr A 30 mm C 365 mm L 170 mm

△ 2 3/7 lbs H 1 1/8" L 14 3/8" W 6 3/8"



RUSTIC BLEND 27021121

Prato Raso 28

Dinner Plate 28

Plato Llano 28

Assiette Plate 28

△ 900 gr A 25 mm Ø 280 mm

△ 2 lbs H 1" Ø 11"



RUSTIC BLEND 27020964

Prato Sobremesa 22

Dessert Plate 22

Plato Postre 22

Assiette Dessert 22

△ 560 gr A 25 mm Ø 220 mm

△ 1 1/4 lbs H 1" Ø 8 3/8"



RUSTIC BLEND 27021122

Prato Sobremesa 22

Dessert Plate 22

Plato Postre 22

Assiette Dessert 22

△ 560 gr A 25 mm Ø 220 mm

△ 1 1/4 lbs H 1" Ø 8 3/8"

RUSTIC BLEND



RUSTIC BLEND 27020962

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml

△ 2 ½ lbs H 1 ¼" Ø 11" CAP. 44 oz



RUSTIC BLEND 27020972

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 1060 gr A 40 mm Ø 280 mm CAP. 1300 ml

△ 2 ½ lbs H 1 ¼" Ø 11" CAP. 44 oz



RUSTIC BLEND 27020961

Prato Fundo 23

Deep Plate 23

Plato Hondo 23

Assiette Creuse 23

△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml

△ 1 ¾ lbs H 1 ¼" Ø 9" CAP. 30 ¾ oz



RUSTIC BLEND 27020971

Prato Fundo 23

Deep Plate 23

Plato Hondo 23

Assiette Creuse 23

△ 720 gr A 40 mm Ø 230 mm CAP. 900 ml

△ 1 ¾ lbs H 1 ¼" Ø 9" CAP. 30 ¾ oz



RUSTIC BLEND 27020965

Prato Sopa 22

Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 780 gr A 50 mm Ø 220 mm CAP. 900 ml

△ 1 ½ lbs H 2" Ø 8 ¾" CAP. 30 ¾ oz



RUSTIC BLEND 27020973

Prato Sopa 22

Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 780 gr A 50 mm Ø 220 mm CAP. 900 ml

△ 1 ½ lbs H 2" Ø 8 ¾" CAP. 30 ¾ oz



RUSTIC BLEND 210020973

Prato Pão 16

Bread & Butter Plate 16

Plato Pan 16

Assiette Pain 16

△ 280 gr A 20 mm Ø 160 mm

△ ½ lbs H ¾" Ø 6 ¾"



RUSTIC BLEND 210021059

Prato Pão 16

Bread & Butter Plate 16

Plato Pan 16

Assiette Pain 16

△ 280 gr A 20 mm Ø 160 mm

△ ½ lbs H ¾" Ø 6 ¾"



RUSTIC BLEND 27020967

Taça 16

Bowl 16

Taza 16

Bol 16

△ 420 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 1 lbs H 1 ¾" Ø 6 ½" CAP. 15 ¾ oz

RUSTIC BLEND



RUSTIC BLEND 27020975

Taça 16

Bowl 16

Taza 16

Bol 16

△ 420 gr A 45 mm Ø 165 mm CAP. 450 ml

△ 1 lbs H 1 7/8" Ø 6 1/2" CAP. 15 3/4 oz



RUSTIC BLEND 27021920

Taça 17

Bowl 17

Taza 17

Bol 17

△ 615 gr A 81 mm Ø 170 mm CAP. 1000 ml

△ 1 3/8 lbs H 3 1/5" Ø 6 3/4" CAP. 33 1/2 oz



RUSTIC BLEND 27021923

Taça 17

Bowl 17

Taza 17

Bol 17

△ 615 gr A 81 mm Ø 170 mm CAP. 1000 ml

△ 1 3/8 lbs H 3 1/5" Ø 6 3/4" CAP. 33 1/2 oz



RUSTIC BLEND 210021081

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm Ø 155 mm CAP. 630 ml

△ 1/2 lbs H 2 3/4" Ø 6 1/8" CAP. 21 1/2 oz



RUSTIC BLEND 210021083

Taça 15,5

Bowl 15,5

Taza 15,5

Bol 15,5

△ 420 gr A 70 mm Ø 155 mm CAP. 630 ml

△ 1/2 lbs H 2 3/4" Ø 6 1/8" CAP. 21 1/2 oz



RUSTIC BLEND 27021921

Taça 12

Bowl 12

Taza 12

Bol 12

△ 340 gr A 60 mm Ø 120 mm CAP. 350 ml

△ 3/4 lbs H 2 3/8" Ø 4 5/8" CAP. 11 1/2 oz



RUSTIC BLEND 27021924

Taça 12

Bowl 12

Taza 12

Bol 12

△ 340 gr A 60 mm Ø 120 mm CAP. 350 ml

△ 3/4 lbs H 2 3/8" Ø 4 5/8" CAP. 11 1/2 oz



RUSTIC BLEND 27021922

Taça 9

Bowl 9

Taza 9

Bol 9

△ 120 gr A 41 mm Ø 85 mm CAP. 100 ml

△ 1/4 lbs H 1 5/8" Ø 3 1/2" CAP. 3 3/8 oz



RUSTIC BLEND 27021925

Taça 9

Bowl 9

Taza 9

Bol 9

△ 120 gr A 41 mm Ø 85 mm CAP. 100 ml

△ 1/4 lbs H 1 5/8" Ø 3 1/2" CAP. 3 3/8 oz



SANDSTORM



SANDSTORM 210020396

Travessa Oval 34

Oval Platter 34

Fuente Oval 34

Plat Ovale 34

△ 1200 gr A 20 mm C 340 mm L 210 mm

△ 3 1/8 lbs H 7/8" L 13 3/8" W 8 1/4"



SANDSTORM 210020397

Travessa Oval 29

Oval Platter 29

Fuente Oval 29

Plat Ovale 29

△ 1000 gr A 25 mm C 290 mm L 180 mm

△ 2 1/8 lbs H 1" L 11 3/4" W 7 1/8"



SANDSTORM 210020398

Travessa Oval 25

Oval Platter 25

Fuente Oval 25

Plat Ovale 25

△ 800 gr A 22 mm C 120 mm L 100 mm

△ 1 3/4 lbs H 7/8" L 4 5/8" W 3 5/8"



SANDSTORM 210020392

Prato Pizza 31

Pizza Plate 31

Plato Pizza 31

Assiette Pizza 31

△ 1300 gr A 30 mm Ø 310 mm

△ 2 5/8 lbs H 1 1/8" Ø 12 1/8"



SANDSTORM 210020324

Prato Raso 27

Dinner Plate 27

Plato Llano 27

Assiette Plate 27

△ 850 gr A 28 mm Ø 270 mm

△ 1 7/8 lbs H 1 1/8" Ø 10 3/8"

SANDSTORM



SANDSTORM 210020325

Prato Raso 23

Dinner Plate 23

Plato Llano 23

Assiette Plate 23

△ 680 gr A 30 mm Ø 235 mm

△ 1 ½ lbs H 1 ¼" Ø 9 ¼"



SANDSTORM 210020327

Prato Sopa 19

Soup Plate 19

Plato Hondo 19

Assiette Creuse 19

△ 515 gr A 50 mm Ø 185 mm

△ 1 ½ lbs H 2" Ø 7 ¾"



SANDSTORM 210020394

Prato Pasta 22

Pasta Plate 22

Plato Pasta 22

Assiette à Pâtes 22

△ 260 gr A 45 mm Ø 250 mm

△ 4 ½ lbs H 1 7/8" Ø 9 5/8"



SANDSTORM 210020326

Prato Sobremesa 20

Dessert Plate 20

Plato Postre 20

Assiette Dessert 20

△ 386 gr A 30 mm Ø 195 mm

△ 6 7/8 lbs H 1 ½" Ø 7 ¾"



SANDSTORM 210020393

Prato Pão 16

Bread & Butter Plate 16

Plato Pan 16

Assiette à Pain 16

△ 250 gr A 20 mm Ø 155 mm

△ 5/8 lbs H 7/8" Ø 6 1/8"

SANDSTORM



SANDSTORM 210020329

Taça 17

Bowl 17

Taza 17

Bol 17

△ 615 gr A 81 mm Ø 170 mm CAP. 1000 ml

△ 1 1/6 lbs H 3 1/5" Ø 6 5/8" CAP. 33 4/5 oz



SANDSTORM 210020330

Taça 12

Bowl 12

Taza 12

Bol 12

△ 320 gr A 60 mm Ø 120 mm CAP. 350 ml

△ 5/7 lbs H 2 3/8" Ø 4 7/8" CAP. 11 5/6 oz



SANDSTORM 210020331

Taça 9

Bowl 9

Taza 9

Bol 9

△ 680 gr A 41 mm Ø 85 mm

△ 1 1/2 lbs H 1 5/8" Ø 3 1/2"



SANDSTORM 210020395

Taça 15

Bowl 15

Taza 15

Bol 15

△ 450 gr A 65 mm Ø 150 mm CAP. 600 ml

△ 1 lbs H 2 5/8" Ø 5 9/8" CAP. 20 3/7 oz



SANDSTORM 210020399

Pires

Saucer

Platillo

Sous-Gobelet

△ 680 gr A 15 mm Ø 145 mm

△ 1 1/2 lbs H 3/8" Ø 5 5/8"



SANDSTORM 210020400

Molheira

Sauceboat

Salsera

Saucière

△ 500 gr A 92 mm C 85 mm L 65 mm CAP. 140 ml

△ 1 1/8 lbs H 3 5/8" L 3 1/5" W 2 5/8" CAP. 4 3/4 oz



SANDSTORM 210020333

Copo 350 ml

Cup 350 ml

Vaso 350 ml

Gobelet 350 ml

△ 350 gr A 107 mm Ø 87 mm CAP. 350 ml

△ 7/8 lbs H 4 2/8" Ø 3 3/8" CAP. 11 5/6 oz



SANDSTORM 210020332

Copo 250 ml

Cup 250 ml

Vaso 250 ml

Gobelet 250 ml

△ 250 gr A 90 mm Ø 85 mm CAP. 250 ml

△ 5/8 lbs H 3 3/8" Ø 3 1/5" CAP. 8 4/5 oz



SANDSTORM 210020328

Copo 78 ml

Cup 78 ml

Vaso 78 ml

Gobelet 78 ml

△ 180 gr A 70 mm Ø 57 mm CAP. 78 ml

△ 3/8 lbs H 2 3/4" Ø 2 1/4" CAP. 2 2/3 oz



SAUVAGE



SAUVAGE 37006442
Travessa 30x16
Platter 30x16
Fuente 30x16
Plateau 30x16
△ 590 gr A 25 mm C 300 mm L 155 mm
△ 1 ½ lbs H 1" L 11 ¼" W 6 ½"



SAUVAGE 37006443
Travessa 25x14
Platter 25x14
Fuente 25x14
Plateau 25x14
△ 560 gr A 20 mm C 250 mm L 140 mm
△ 5 ¼ lbs H ¾" L 9 ¾" W 5 ½"




SAUVAGE 37006444
Travessa 20x10
Platter 20x10
Fuente 20x10
Plateau 20x10
△ 195 gr A 20 mm C 200 mm L 100 mm
△ ¾ lbs H ¾" L 7 ¾" W 4"



SAUVAGE 37003612
Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41
△ 2415 gr A 55 mm Ø 410 mm
△ 5 ½ lbs H 2 ½" Ø 16 ½"



SAUVAGE 37003608
Travessa Oval 39
Oval Platter 39
Fuente Oval 39
Plat Ovale 39
△ 1580 gr A 35 mm C 385 mm L 330 mm
△ 3 ½ lbs H 1 ¾" L 15 ½" W 13"



SAUVAGE 37003609
Prato Marcador 34
Charger Plate 34
Plato Presentación 34
Assiette de Présentation 34
△ 1111 gr A 35 mm Ø 335 mm
△ 2 ½ lbs H 1 ¾" Ø 13 ½"



SAUVAGE 37003592
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 865 gr A 25 mm Ø 280 mm
△ 1 ¾ lbs H 1" Ø 11"

SAUVAGE



SAUVAGE 37003595

Prato Pasta 28

Pasta Plate 28

Plato Pasta 28

Assiette Pâtes 28

△ 830 gr A 45 mm C 280 mm L 270 mm CAP. 650 ml

△ 1 5/8 lbs H 1 7/8" L 11" W 10 5/8" CAP. 22 oz



SAUVAGE 37005303

Prato Sopa 22


Soup Plate 22

Plato Hondo 22

Assiette Creuse 22

△ 592 gr A 45 mm C 220 mm L 210 mm CAP. 550 ml

△ 1 3/7 lbs H 1 7/8" L 8 2/3" W 8 1/4" CAP. 18 3/5 oz



SAUVAGE 37003593

Prato Sobremesa 24

Dessert Plate 24

Plato Postre 24

Assiette Dessert 24

△ 471 gr A 25 mm C 235 mm L 230 mm

△ 1 lbs H 1" L 9 1/4" W 9"



SAUVAGE 37003607

Saladeira 26


Salad Bowl 26

Ensaladera 26

Saladier 26

△ 1000 gr A 110 mm C 260 mm L 250 mm CAP. 1520 ml

△ 2 3/5 lbs H 4 1/3" L 10 1/4" W 9 5/8" CAP. 51 2/3 oz



SAUVAGE 37003610

Prato Pão 18

Bread & Butter Plate 18

Plato Pan 18

Assiette à Pain 18

△ 346 gr A 25 mm Ø 175 mm

△ 3/4 lbs H 1" Ø 6 8/9"



SAUVAGE 37003594

Taça 17

Bowl 17

Taza 17

Bol 17

△ 400 gr A 55 mm C 170 mm L 155 mm CAP. 450 ml

△ 8/9 lbs H 2 1/8" L 6 2/3" W 6 1/8" CAP. 15 2/3 oz



SAUVAGE 37005302

Taça 11

Bowl 11

Taza 11

Bol 11

△ 146 gr A 35 mm C 105 mm L 100 mm CAP. 70 ml

△ 1/3 lbs H 1 3/8" L 4 1/8" W 3 3/8" CAP. 2 2/3 oz



SAUVAGE 37003606

Caneca 400 ml

Mug 400 ml

Jarra 400 ml

Gobelet 400 ml

△ 366 gr A 110 mm C 120 mm L 90 mm CAP. 400 ml

△ 5/8 lbs H 4 1/3" L 4 5/8" W 3 1/2" CAP. 13 1/2 oz



SAUVAGE 37003611

Copo 340 ml

Cup 340 ml

Vaso 340 ml

Verre 340 ml

△ 364 gr A 110 mm Ø 90 mm CAP. 340 ml

△ 1/2 lbs H 4 1/3" Ø 3 1/2" CAP. 11 1/2 oz



SHANGRI-LA ORO



SHANGRI-LA ORO 37006445
Travessa 30x16
Platter 30x16
Fuente 30x16
Plateau 30x16
△ 590 gr A 25 mm C 300 mm L 155 mm
△ 1 1/5 lbs H 1" L 11 3/4" W 6 1/8"



SHANGRI-LA ORO 37006446
Travessa 25x14
Platter 25x14
Fuente 25x14
Plateau 25x14
△ 560 gr A 20 mm C 250 mm L 140 mm
△ 5 1/4 lbs H 4/5" L 9 3/8" W 5 1/2"



SHANGRI-LA ORO 37006447
Travessa 20x10
Platter 20x10
Fuente 20x10
Plateau 20x10
△ 195 gr A 20 mm C 200 mm L 100 mm
△ 3/7 lbs H 4/5" L 7 7/8" W 4"



SHANGRI-LA ORO 37006210
Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41
△ 2415 gr A 55 mm Ø 410 mm
△ 5 1/5 lbs H 2 1/8" Ø 16 1/2"



SHANGRI-LA ORO 37006100
Travessa 38
Platter 38
Fuente 38
Plat 38
△ 1580 gr A 35 mm C 380 mm L 305 mm
△ 1/2 lbs H 1 3/8" L 15" W 12"



SHANGRI-LA ORO 37006212
Travessa 24
Platter 24
Fuente 24
Plat 24
△ 523 gr A 23 mm C 239 mm L 190 mm
△ 1 1/5 lbs H 8/5" L 9 3/8" W 7 1/2"



SHANGRI-LA ORO 37006206
Prato Marcador 33
Charger Plate 33
Plato Presentación 33
Assiette de Présentation 33
△ 1111 gr A 25 mm Ø 325 mm
△ 2 4/5 lbs H 1" Ø 12 3/4"



SHANGRI-LA ORO 37006097
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 770 gr A 25 mm C 281 mm L 279 mm
△ 1 3/5 lbs H 1" L 11" W 11"



SHANGRI-LA ORO 37006209
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 25 mm Ø 230 mm
△ 1 3/5 lbs H 1" Ø 9"

SHANGRI-LA



SHANGRI-LA ORO 37006208
Prato Sobremesa 22
Dessert Platter 22
Plato Postre 22
Assiette Dessert 22
△ 544 gr A 20 mm Ø 220 mm
△ 1 ½ lbs H 1" Ø 8 ¾"



SHANGRI-LA ORO 37006099
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 253 gr A 22 mm C 179 mm L 172 mm
△ ½ lbs H 7/8" L 7" W 6 7/8"



SHANGRI-LA ORO 37006081
Prato Pasta 26
Pasta Plate 26
Plato Pasta 26
Assiette à Pâtes 26
△ 722 gr A 60 mm Ø 255 mm
△ 1 ¾ lbs H 2 ¾" Ø 10"



SHANGRI-LA ORO 37006211
Saladeira 27
Salad Bowl 27
Ensaladera 27
Saladier 27
△ 1175 gr A 110 mm Ø 265 mm
△ 2 ¾ lbs H 4 ½" Ø 10 ¾"



SHANGRI-LA ORO 37006207
Taça 12
Bowl 12
Taza 12
Bol 12
△ 341 gr A 50 mm Ø 120 mm
△ ¾ lbs H 2" Ø 4 5/8"



SHANGRI-LA ORO 37006098
Taça 17
Bowl 17
Taza 17
Bol 17
△ 400 gr A 55 mm C 155 mm L 170 mm
△ 7/8 lbs H 2 ¼" L 6 ½" W 6 5/8"



SHANGRI-LA ORO 37006213
Copo 340 ml
Cup 340 ml
Vaso 340 ml
Gobelet 340 ml
△ 364 gr A 110 mm Ø 90 mm CAP. 340 ml
△ ¾ lbs H 4 ½" Ø 3 5/8" CAP. 11 ½ oz



SHANGRI-LA ORO 37006082
Caneca 340 ml
Mug 340 ml
Jarra 340 ml
Tasse 340 ml
△ 384 gr A 110 mm C 130 mm L 90 mm
△ ¾ lbs H 4 ½" L 5 ½" W 3 5/8"



SHANGRI-LA ORO 37006396
Copo 70 ml
Cup 70 ml
Vaso 70 ml
Gobelet 70 ml
△ 100 gr A 65 mm Ø 60 mm CAP. 70 ml
△ ¼ lbs H 2 5/8" Ø 2 ½" CAP. 2 ¾ oz



SHANGRI-LA VINE



SHANGRI-LA VINE 37006448
Travessa 30x16
Platter 30x16
Fuente 30x16
Plateau 30x16
△ 590 gr A 25 mm C 300 mm L 155 mm
△ 1 ½ lbs H 1" L 11 ¼" W 6 ½"



SHANGRI-LA VINE 37006449
Travessa 25x14
Platter 25x14
Fuente 25x14
Plateau 25x14
△ 560 gr A 20 mm C 250 mm L 140 mm
△ 5 ¼ lbs H ¾" L 9 ¾" W 5 ½"



SHANGRI-LA VINE 37006450
Travessa 20x10
Platter 20x10
Fuente 20x10
Plateau 20x10
△ 195 gr A 20 mm C 200 mm L 100 mm
△ ¾ lbs H ¾" L 7 ¾" W 4"



SHANGRI-LA VINE 37006107
Travessa Redonda 41
Round Platter 41
Fuente Redonda 41
Plat Rond 41
△ 2415 gr A 55 mm Ø 410 mm
△ 5 ½ lbs H 2 ½" Ø 16 ½"



SHANGRI-LA VINE 37006199
Travessa Oval 38
Oval Platter 38
Fuente Oval 38
Plat Ovale 38
△ 1580 gr A 35 mm C 380 mm L 305 mm
△ ½ lbs H 1 ¾" L 15" W 12"



SHANGRI-LA VINE 37006201
Travessa 24
Platter 24
Fuente 24
Plat 24
△ 523 gr A 23 mm C 239 mm L 190 mm
△ 1 ½ lbs H ¾" L 9 ¾" W 7 ½"



SHANGRI-LA VINE 37006083
Prato Marcador 33
Charger Plate 33
Plato Presentación 33
Assiette de Présentation 33
△ 1111 gr A 25 mm Ø 325 mm
△ 2 ¼ lbs H 1" Ø 12 ¾"



SHANGRI-LA VINE 37006196
Prato Raso 28
Dinner Plate 28
Plato Llano 28
Assiette Plate 28
△ 770 gr A 25 mm C 281 mm L 279 mm
△ 1 ½ lbs H 1" L 11" W 11"



SHANGRI-LA VINE 37006106
Prato Sopa 23
Soup Plate 23
Plato Hondo 23
Assiette Creuse 23
△ 698 gr A 25 mm Ø 230 mm
△ 1 ½ lbs H 1" Ø 9"

SHANGRI-LA



SHANGRI-LA VINE 37006085
Prato Sobremesa 22
Dessert Platter 22
Plato Postre 22
Assiette Dessert 22
△ 544 gr A 20 mm Ø 220 mm
△ 1 ½ lbs H 1" Ø 8 ¾"



SHANGRI-LA VINE 37006198
Prato Pão 18
Bread & Butter Plate 18
Plato Pan 18
Assiette à Pain 18
△ 253 gr A 22 mm C 179 mm L 172 mm
△ 5/9 lbs H 7/8" L 7" W 6 7/8"



SHANGRI-LA VINE 37006200
Prato Pasta 26
Pasta Plate 26
Plato Pasta 26
Assiette à Pâtes 26
△ 722 gr A 60 mm Ø 255 mm
△ 1 ¾ lbs H 2 ¾" Ø 10"



SHANGRI-LA VINE 37006108
Saladeira 27
Salad Bowl 27
Ensaladera 27
Saladier 27
△ 1175 gr A 110 mm Ø 265 mm
△ 2 ¾ lbs H 4 ½" Ø 10 ¾"



SHANGRI-LA VINE 37006084
Taça 12
Bowl 12
Taza 12
Bol 12
△ 341 gr A 50 mm Ø 120 mm
△ ¾ lbs H 2" Ø 4 5/8"



SHANGRI-LA VINE 37006197
Taça 17
Bowl 17
Taza 17
Bol 17
△ 400 gr A 55 mm C 155 mm L 170 mm
△ 7/8 lbs H 2 ¼" L 6 ½" W 6 5/8"



SHANGRI-LA VINE 37006109
Copo 340 ml
Cup 340 ml
Vaso 340 ml
Gobelet 340 ml
△ 364 gr A 110 mm Ø 90 mm CAP. 340 ml
△ ¾ lbs H 4 ½" Ø 3 5/8" CAP. 11 ½ oz



SHANGRI-LA VINE 37006202
Caneca 340 ml
Mug 340 ml
Jarra 340 ml
Tasse 340 ml
△ 384 gr A 110 mm C 130 mm L 90 mm
△ 6/7 lbs H 4 ½" L 5 ½" W 3 5/8"




SHANGRI-LA VINE 37006397
Copo 70 ml
Cup 70 ml
Vaso 70 ml
Gobelet 70 ml
△ 100 gr A 65 mm Ø 60 mm CAP. 70 ml
△ ¼ lbs H 2 5/8" Ø 2 ½" CAP. 2 ¾ oz







TISSÉ




TISSÉ BLUE 37006066
Prato Marcador 33
Charger Plate 33
Plato Presentación 33
Assiette de Présentation 33
△ 1245 gr A 20 mm Ø 330 mm
△ 2 ¾ lbs H 7/8" Ø 13"



TISSÉ BLUE 37006067
Prato Raso 27
Dinner Plate 27
Plato Llano 27
Assiette Plate 27
△ 645 gr A 25 mm Ø 265 mm
△ 1 ¾ lbs H 1" Ø 10 3/4"




TISSÉ BLUE 37006069
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 505 gr A 45 mm Ø 215 mm
△ 1 1/8 lbs H 1 7/8" Ø 8 5/8"



TISSÉ BLUE 37006068
Prato Sobremesa 24
Dessert Plate 24
Plato Postre 24
Assiette Dessert 24
△ 420 gr A 20 mm Ø 225 mm
△ 8/8 lbs H 7/8" Ø 8 5/8"



TISSÉ BLUE 37006087
Taça 18
Bowl 18
Taza 18
Bol 18
△ 400 gr A 58 mm Ø 181 mm
△ 7/8 lbs H 2 3/4" Ø 7 1/8"




TISSÉ BLACK 37006071
Prato Raso 27
Dinner Plate 27
Plato Llano 27
Assiette Plate 27
△ 645 gr A 25 mm Ø 265 mm
△ 1 3/4 lbs H 1" Ø 10 3/4"



TISSÉ BLACK 37006070
Prato Marcador 33
Charger Plate 33
Plato Presentación 33
Assiette de Présentation 33
△ 1245 gr A 20 mm Ø 330 mm
△ 2 3/4 lbs H 7/8" Ø 13"



TISSÉ BLACK 37006086
Taça 18
Bowl 18
Taza 18
Bol 18
△ 400 gr A 58 mm Ø 181 mm
△ 7/8 lbs H 2 3/4" Ø 7 1/8"



TISSÉ BLACK 37006072
Prato Sobremesa 24
Dessert Plate 24
Plato Postre 24
Assiette Dessert 24
△ 420 gr A 20 mm Ø 225 mm
△ 8/9 lbs H 7/8" Ø 8 5/8"



TISSÉ BLACK 37006073
Prato Sopa 22
Soup Plate 22
Plato Hondo 22
Assiette Creuse 22
△ 505 gr A 45 mm Ø 215 mm
△ 1 1/9 lbs H 1 7/8" Ø 8 3/8"

hotelware.vistaalegre.com